# **PHILIPS**

Service Manual

Philips EP 1200 series 2200 series 3200 series

– max

-

- 🗊

- 🕏

My Coffee Choice

PHILIPS

## Contents

## **General information**

: 1.8 litres removable

996530067222

132253695601

996530045784

Descaler

• Jar of Grease

Silicone grease

•

•

Version history	41	Maintenance product	ts	
Repair Flow				
Reset drinks settings to default setting		(WxDxH)		
Deactivate the beeping sound of the buttons		-Dimensions of product : 2	246 x 372 x 433 m	
Deactivate AquaClean filter reminder		Weight and dimensions:     _Weight of product	· 7 - 75 kg	
Espresso Philips Service Center (EPSC)		Adjustable spout height	: 85 - 145 mm	
Temporany solutions		Pump pressure	: 15 bar	
Descaling		Cord lengh	: 1 m	
Steam out		Capacity Coffee grounds	: 12 pucks	
Functions/features explanation	33	Capacity LatteGo	: 250 ml	
lest mode	25	Capacity coffee bean	: 275 g	
Test mode	22	Capacity water tank	: 1.8 litres removal	
Disassembly- and Reassembly advice	15	Auto shut-off time	: 15 min	
		<ul> <li>Standby power consumption: 0.22 W</li> </ul>		
Brew Unit mainteinance - where to grease and positions		Power consumption	: 1450 W	
Operating logic		Frequency	: 50 - 60 Hz	
Specification for the measurement of the Milk products temperature.		<ul> <li>Voltage</li> </ul>	: 220 - 240 V	
Specification for the measurement of the co	ffee products temperature	Technical information	n	
Specific tools and equipment				
Coffee and machine specifications				
Water circuit				
Technical information	4			
Overview				
Optional (accessories)				
Production date (or serial number)				
Maintenance products				
Technical information				

### Important repair instructions

- Only skilled personnel should carry out the repair.
- After repair the appliance should function properly.
- After repair the appliance has to meet the regulatory- and safety requirements that were applicable at the time of release of the model.
- After repair the appliance always has to be tested for electrical safety according VDE 0701-0702 and for medical products IEC 62353.

### **Philips EP Series**



## **Production date (or serial number)**



## **Optional (accessories)**

- AquaClean water filter CA6903
- Descaling solution CA6700
- Brew group grease HD5061
- Coffee oil remover tablets CA6704



# **General information**

# **General information**

### Overview

CMF (classic milk frother)











Latte Go





# **Technical information**

### Water circuit



## **Electric circuit**



### **Philips EP Series**

# **Technical information**

### Coffee and machine specifications

	- Low button	Medium button	High button	Volume adjustment
Drinks	(ml)	(ml)	(ml)	(only at high button - ml)
Espresso	30	40	70	40-220
Coffee	100	120	200	120-220
Espresso lungo	60	80	180	80-220
Americano (water)	40 (50)	40 (110)	40 (160)	40 (110-360)
Cappuccino (milk)	30 (90)	40 (120)	60 (200)	40-220 (120-340)
Latte macchiato (milk)	30 (120)	40 (200)	50 (340)	40-220 (200-340)
Hot water	60	150	360	150-360
Coffee g	rounds drawer		Description and	values
Time-out for c	offee grounds drawer		5 seconds	:
Reset	dreg counter	Dreg emptyi	ng alarm, if the coffee gro more than 5 sec	ounds drawer is removed for conds.
S	TANDBY		Description and	values
Tim	e (default)		15 minute	S
Time programmed by Consumer/Service NO				
Boiler temper	ature during Standby	Standby Boiler OFF		:
WA	TER TANK		Description and	values
Water reserve (p	oulses) with water filter		125 ml (260 pi	ulses)
Water reserve (pu	Ilses) with no water filter	125 ml (260 pulses)		ulses)
Water reserve modifiable b	y Production/Service departme	ents	NO	
"Fill	tank" alarm		YES	
Connect	to water mains		NO	
Specific tools and	l equipment			
De	escription		Notes	
Flathea	ad screwdriver		# 0, # 2	
Torx	screwdriver		(T10)	
Pliers for	r Oetiker clamps			
Digital	Thermometer	Type K (accuracy for temperature of 0,05 % or $\pm$ 0,3°C)		e of 0,05 % or ± 0,3°C)
Tempe	erature probe	80PK-22 (80AK-A Thermocouple adapter required)		ple adapter required)
Scale KERN EMB 500-1 or comparable device with a base ac		rice with a base accuracy of		

Scale	
Power meter	
Stopwatch	

Serkit

EP series cable

EPSC (Espresso Philips Service Center)

Voltcraft EnergyCheck 3000 or comparable device with a base accuracy of 1 % or ± 5W

Basic model

Tool needed for programming with our service tool

Cable for Philips EP1200-2200-3200 series

Tool used to flash the SW on the machines (for SW upgrade and diagnostics mode). Refer to SDA\_114585



### Specification for the measurement of the coffee products temperature

Before measuring the in-cup temperature make sure the following conditions will be met:

### Conditions:

- a) Water temperature in tank:  $23^{\circ}C(+/-2^{\circ}C)$
- b) Use a plastic cup (see picture 1).
- c) Use a digital thermometer (see picture 2) (e.g. type K probe diameter max 2mm (see picture 3).

d) The coffee machine is tested without any change of parameters or calibrations, which may affect the temperature of products, so the measurement of temperature must be done with machine in default factory setting.

### Procedure:

- 1. Place the plastic cup under the dispensing spout. (picture 1)
- 2. Dispense coffee
- 3. Measure the temperature immediately after coffee has being dispensed, you need to finish the measurement within 12 seconds. The temperature in the cup is measured by placing the probe of the thermometer in the cup near the bottom. Then stir the probe in the cup for 5 to 6 times and read out the thermometer values during stirring. Hold the probe still in the center of the cup.
- 4. Record the highest value.

Depending on the coffee volume selected to measure, you would need to position the probe on several height levels to measure the correct temperature in the plastic cup.

10mm for 35gr - 17mm for 60gr - 35mm for 120gr (see Picture 3).

Espresso Coffee Italy Q.ty 40 gr. Temperature of 1st product 69°C ≤ 85°C Temperature of 2nd product  $72^{\circ}C \le 85^{\circ}C$ 

Coffee Q.ty 120 gr. Temperature of 1st product  $72^{\circ}C \le 85^{\circ}C$ 







OFF

Tare ON

DISPLAY

# **Technical information**

## Specification for the measurement of the Milk products temperature.

Before measuring the milk froth temperature and milk froth height make sure the following conditions will be met:

### Conditions:

a) Use semi skimmed UHT milk with a fat percentage between 1.5 - 1.8% b) Milk is cooled between 4 – 8°C (refrigerator temperature). c) Use a plastic transparent measuring beaker which can hold min 250mL with an inner diameter of 70mm. d) Use a digital thermometer (see picture 2, page 8) (e.g. type K probe diameter max 2mm (see picture 3, page 8).

Depending on the frothing system, the applicable specification need to be selected to determine if the appliance is within specification.

### Available systems:

Manual system pannarello (CMF)

Temperature specification: delta ≥ 45°C Froth height specification: ≥ 15mm on 100gr. of brewed milk product

Automatic system (Latte Go)

Temperature specification: delta  $\geq$  60°C Froth height specification: ≥ 15mm on 100gr. of brewed milk product

### Milk temperature in the beaker:

- System with CMF: With milk at Trefr. (about 4-10 °C):  $\Delta \ge 45$
- System with LatteGo: With milk at Trefr. (about 4-8 °C):  $\Delta \ge 60$

### How does it work:

- 1. The milk is heated in the first chamber of the carafe thanks to the steam.
- 2. Then, it is mixed with air and frothed in the middle chamber.
- 3. Finally, in the outlet chamber, the 'typhoon effect' perfects the milk texture by removing the large bubbles



### Procedure to measure the temperature of the milk.

- 1. Place the beaker under the milk spout.
- 2. Dispense 100gr of milk froth.
- 3. Measure the temperature immediately after milk froth is dispensed, you need to finish the measurement within 5 seconds.
- 4. The temperature is measured by placing the probe of the thermometer  $\pm$  10mm above the bottom of the beaker.
- 5. Then stir the probe for 3 to 5 times and read out the thermometer values during stirring, values should stabilize.
- 6. Hold the probe still in the center of the beaker and read out the temperature.





### Procedure to measure the milk froth height.

### Manual system (CMF)

Pour 100cc. of milk at Trefr. in a beaker of 250 ml of capacity and with a inner diameter of 70 mm; with machine in steam mode:

- 1. Place the beaker with the frother dipped in milk, dispensing steam and start the chronometer.
- 2. After about 30 to 60 seconds, stop the steam and check the result on milk.

### Automatic system (Latte Go)

After setting the machine to delivery of 120gr. of product:

- 1. Launch the "hot milk" function.
- 2. Collect the product in a beaker with a 250ml of capacity and with an inner diameter of 70 mm, and verify the result obtained on milk. Carry out the test using milk at a Trefr..

In case the machine allows modify of the emulsion through the menu, use the machine with the emulsion set to the default value.

Related to the above testing procedure derives the following table of acceptability:

Grams of product	Minimun height of the milk cream
≥ 130	≥ 30mm
120	≥15mm
110	≥ 22mm
100	≥ 20mm
90	≥ 16mm
80	≥ 13mm
70	≥ 11mm

To verify the height of the cream, a practical example is to add to dispensed product a small amount of coffee. The addition of coffee immediately highlights the surface of separation between liquid and cream.

# **Technical information**

## **Operating logic**

### Switching on

When the machine is switched on, the gear motor repositions itself as follows: - It acts on microswitch 1

- The gear motor changes its rotation direction and moves upwards again by approx. 1-2 mm.
- The boiler begins to heat the water for approx. 45 sec, in order to reach the optimal temperature (established by the software).



The gear motor is powered by a direct current motor that engages with the smaller double toothed wheel using a worm screw. The unit is mounted on the axle of the large gear wheel and when a coffee is requested, it moves from the standby position to the dispensing position, and then back to the standby position again. The microswitch indicates to the gear motor when the brew group is in the work position or home position.

- Standby position: 1
- Dispensing position: 2

### Temperature sensor (adjustment)

Temp. (°C)	R nom (kΩ)	ΔR (+/- %)
20	61.465	4.0
50	17.617	3.1
75	7.214	2.4
80	6.121	2.3
85	5.213	2.2
90	4.459	2.1
100	3.3	1.8
125	1.653	2.4
150	0.893	2.8

An NTC is used as a temperature sensor; in the event of overheating this reduces boiler element power consumption. The electronic system detects the current boiler temperature from the drop in voltage of the sensor and adjusts it accordingly. Heating element values and corresponding temperatures: see table.





# **Technical information**

# **Technical information**

### **Coffee grinder**



The coffee grinder is driven by a direct current motor (1) using a worm screw helicoidal wheel transmission (2). The worm screw (2) drives a plastic gear wheel (3), which turns the lower grinder (4) and the increment pin (5)

### **Coffee grinder blocked**

When the coffee grinder is working, the software monitors the current consumption. If the current value is very high, the machine concludes that the coffee grinder is blocked; instead, if the current value is in the middle, the machine concludes that all is ok and it goes on to do the product.

Because the current consumption of grinder changes depending on the situations (motor new or old, cold or hot, coffee blends, etc.), these current targets are not static, but dynamic.





1) Steam inlet

Steam flows into the LatteGo





### **Philips EP Series**

2) Complete LatteGo milk container assy

Air, steam and milk are mixed at high speed resulting in a dense silky smooth milk foam

The two LatteGo parts clicked together create a channel in which steam pressure sucks up milk througt the hole at the bottom of the container

The water level is monitored by a capacitive sensor, located one third of the way up

If the electronics assembly detects, by means of the sensor, that the amount of water in the tank has dropped below the above mentioned level, a water reserve remains available for the dispensing process underway (this will cover 200 flow

The product dispensing process will then come to an end.

If a dispensing cycle ends after the sensor has been triggered (in the reserve) then the display "Water low" continues to be displayed during the following dispensing



# **Technical information**

### AquaClean water filter

The AquaClean filter is designed to reduce limescale deposits in the coffee machine and provide filtered water to preserve the aroma and flavor of each cup of coffee. By using a series of 8 AquaClean filters, there is no need to descale the machine for 5000 cups (It depends both on the type of coffee used, rinsing and cleaning programs).

We recommend installing the water filter AquaClean the first use of the machine to the maximum before using 5 L of water. The machine display will indicate when the filter needs to be replaced. The maximum limit is equivalent to 110 L of water.

The conditions related to the filter work environment (water, therefore, an active environment for bacteria and microorganisms), require the replacement with a minimum frequency (we suggest 3 months from the activation to ensure the best performance). The filter starts' working from the time is filled with water and continues working even with the machine off. It cannot be deactivated manually, as it must end its life cycle.

At the filter activation the display shows the icon with the percentage of use:

- Initially 100% then decreasing.

When the autonomy of the current filter becomes less than 8 L of water the display shows:

- The icon flashing slowly. It means 10%.

When the autonomy of the current filter becomes less than 2 L of water the display shows

- The icon flashing quickly. It means 0%.

After a maximum of 110 L of water supplied the flashing light turn off and the machine needs to be descaled.

### **Descaling request**

### **Descaling frequency in AQUACLEAN** The first activation must make before you've paid up to 5000ml products because mind thinks as if he had the filter Percentual on Percentual on display 10% the display 0% the MAX Quantity icon flashes slowly. icon flashes water, the icon Filter number Hardness turns off. (repla-(encourage the quickly. (tell the consumer to buy consumer to ce filter) the filter) change the filter)

Indifferent	From 1/8 to 7/8	8050ml	2000ml	62500ml 75000ml only	Replace filter (you can not tur off)
	8/8				Descaling

If after descaling or after the use of a filter this is not reactivated , the machine recognizes the water hardness setting and calculates as in the table below

Descaling cycle frequency					
Hardness WATER HARDNESS Without water filter Not reactivating the filter					
1	Soft (up to 7°dH)	240 litres (480,000 pulses)	210 litres (420,000 pulses)		
2	Medium (7° - 14°dH)	120 litres (240,000 pulses)	105 litres (210,000 pulses)		
3	Hard (15° - 21°dH)	60 litres (120,000 pulses)	52.5 litres (105,000 pulses)		
4 Very hard (over 21°dH) 30 litres (60,000 pulses) 26.25 litres (52,500 pulses)					
The default water hardness level is 4. Each litre of water corresponds to approximately 2,000 pulses.					

### **Philips EP Series**

### Brew Unit mainteinance - where to grease and positions









Work Position





Before you start dismantling!

For your safety be sure the plug is disconnected from the mains!

The product is designed for easy access to the internal components. Make sure that all accessories have been removed.



## Removal of the housing:

- 1. Make sure the power cable is unplugged.
- 2. Take out the four screws and pull up the upper cover.



### **Philips EP Series**

# **Disassembly - and Reassembly advice**

3. When assemby the finger-protection screw:

- Up to SN TW901907111749 use torque force 1.2Nm +/- 0.1
- From SN TW901907111750 use torque force 0.8Nm +/- 0.1
- 4. Take out the two screws in the back panel and remove it.



5. To remove the two laterals panel take out 3 screws for each of them





# **Disassembly - and Reassembly advice**

## Removal of the UI

1. To remove the UI push the 2 snaps inside (indicated with the red arrows):



### 2. Then unplug the cable.

Do not use a screwdriver, but pull it keeping the flat cable and not the connector (some force is required)



3. Click on the 4 snaps to remove the UI board protection.



## **Philips EP Series**

4. To re-mount the UI start keeping inserted first the upper part of the cover, then push it. Make sure the 4 snaps are properly closed



## **Removal of the Grinder**

1. Pull out the grinder assy 2. Remove the electric connections

## **Removal of the Electrovalves**

1. For the upper EV pull outwards the valve holder.

2. For the lateral EV take out the 2 screws, then remove the valve.





19

### Removal of the Gear motor

1. Take out the brew unit motor cover removing the 2 screws



### **Removal of the Boiler**

1. Remove all the electrical and water circuit connections

2. Take out the 2 screws from the boiler support.



### **Removal of the Flowmeter**

- 1. Remove the electric connection
- 2. Press on the holder to pull out the flowmeter, then remove water connections.



## **Philips EP Series**

**Removal of the Mainboard** 

- 1. Remove all the electric connections
- 2. Keep pressing on the left holder to be able to release the board. The mainboard contains several fixed wires which cannot be disconnected from the board. The UI cable is also fixed to the mainboard.

To completely remove the mainboard from the appliance, disconnect all fixed wires from their destination component.



### **Removal of the Pump**

1. Pull the pump holder to the right

2. Remove all the connection

When reassembling the pump, ensure to use hot melt to fix the thermal fuse.







### **Removal of the Coffee and Water spout**

- 1. To remove the front panel start at the lower snap (1). Push to the left and on top of it, then the cover opens at the front side and you can put a finger (nail) in between. Then push on the upper snap nock (2).
- 2. Pull down the coffee spout, then remove the pipe.



3. Take out the 2 screws

4. Unsnap the click (as shown in picture) and pull the front case cover to remove it (some force is needed).



5. Remove the two screws to release the water spout.



## **Removal of the Microswitch**

1. To remove the microswitch please take extra care, slowly pulling it out from its place, then remove the connections.





## **Test mode**

## Introduction

Test mode is used to test the machine in its mechanics and electronic components

## How it works

The machine enters in test mode by pressing in sequence B5 - B2 - B4 - B3 in the first two seconds after switching on the machine, by connecting the power cable to the mains.

Once entered the machine shows led L1 and L2 flashing in series (Level 0).



# **Test mode**

There are 3 different levels, in each level the coffee-machine can execute different commands,

- Level 0: Entry Level; in this level the operator can
- Level 1: In this level the operator can
  - 1. test all the Buttons and Leds activation and color: a. Buttons : B1, B2, B3, B4, B5, B6, B7, B8, B9, B10, B11, B12, B13. L22(O), L23(O), L24(R), L25(R), L26(R), L27(O) 2. Check the buzzer sound.
- Level 2: In this level the operator can: 1. Test all the loads:
  - a. Move the Brew Unit upward and downward. b. Open/Closed the EVs. c. Start the Pump. d. Start the Heater e. Start the Grinder 2. Test all the sensors:
    - a. Microswitch door activated/not activated. b. Microswitch BU position (work/home) activated/not activated.
    - c. Hall sensor water level activated/not activated.
    - d. Flowmeter
    - e. NTC

The user can switch the level by pressing the Button B1, while pushing the button the machine shows the level of the test:

> a) Level 1 : Led L1 ON (O), b) Level 2 : Led L1 ON (O), Led L2 ON (O)

_egend:	Pressing button Stand-B
0) = Orange	
B) = Blu	TEST
R) = Red	Pressing button Stand-B

At the start up all loads are turned off. The software allow to have multiple loads active at the same time.

## **Philips EP Series**

1. execute the Reset of the error log by pressing B3 for 3s (L24-L25-L26 will flash to confirm)

b. Leds :L1(O), L2(O), L3(O), L4(O), L5(O), L6(O), L7(O), L8(O), L9(O), L10(O), L11(O), L12(0), L13(0), L14(0), L15(0), L16(0), L17(0), L18(0), L19(B), L20(0), L21(0),

TEST MODE Level0 Зy MODE Level1 Pressing button Stand-By Зy **TEST MODE Level2** 



# Test mode

## Level 0 (Start test mode)

Start condition: NO BU, NO drag drawer,	LED INDICATION
Door open, No Water	L1 and L2 Blink Alternately

## Level 1 (Keys, Buzzer, Leds)

Start condition: NO BU, NO drag drawer,	LED INDICATION
Door open, No Water	All Leds OFF

Sequence of actions by user	Reaction of the appliance			
	PASS FAIL Cause of failure			Solution
Press button B2		L1 OFF	L1 damaged	Change UI boad
		L1(!O) ON	L1 wrong color	Change UI boad
		Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
	L1(O) ON, It's possible to hear the feedback sound.	lt's not possible to hear the sound	The drive of the Buzzer or the Buzzer in the Main is damaged	Change Main Board
		The sound is persistent	The drive of the Buzzer or the Buzzer in the Main is damaged	Change Main Board
Press button B2		L2 OFF	L2 damaged	Change UI boad
		L2(!O) ON	L2 wrong color	Change UI boad
	E1(0) & E2(0) ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B2 (optional)	L1 & L2 OFF			
Press button B4		L5 OFF	L5 damaged	Change UI boad
	15(O) ON	L5(!O) ON	L5 wrong color	Change UI boad
	20(0) 011	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B4		L6 OFF	L6 damaged	Change UI boad
		L6(!O) ON	L6 wrong color	Change UI boad
	L3(O) & L0(O) ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B4 (optional)	L5 & L6 OFF			
Press button B6		L8 OFF	L8 damaged	Change UI boad
(only 3B&3C)	1.8(O) ON	L8(!O) ON	L8 wrong color	Change UI boad
	20(0) 011	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B6		L9 OFF	L9 damaged	Change UI boad
(only 3B&3C)		L9(!O) ON	L9 wrong color	Change UI boad
	20(0) 0 20(0) 01	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B6 (optional)	L8 & L9 OFF			
Press button B3		L3 OFF	L3 damaged	Change UI boad
	1.3(O) ON	L3(!O) ON	L3 wrong color	Change UI boad
	20(0) 011	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad

# Test mode

Press button B3		L4 OFF	L4 damaged	Change UI boad
(only 2A)	L3(0) & L4(0) ON L4(!O) ON		L4 wrong color	Change UI boad
	L3(0) & L4(0) ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B3 (optional)	L3 & L4 OFF			
Press button B5		L7 OFF	L7 damaged	Change UI boad
		L7(!O) ON	L7 wrong color	Change UI boad
		Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B5 (optional)	L7 OFF			
Press button B7		L10 OFF	L10 damaged	Change UI boad
(only 3B&3C)		L10(!O) ON	L10 wrong color	Change UI boad
	210(0) 011	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B7 (optional)	L10 OFF			
Press button B8		L11 OFF	L11 damaged	Change UI boad
		L11(!O) ON	L11 wrong color	Change UI boad
		Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B8		L12 OFF	L12 damaged	Change UI boad
	L11(O) & L12(O)	L12(!O) ON	L12 wrong color	Change UI boad
	ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B8		L13 OFF	L13 damaged	Change UI boad
	L11(O) & L12(O)	L13(!O) ON	L13 wrong color	Change UI boad
	& L13(O) ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B8	111(0) 8112(0)	L14 OFF	L14 damaged	Change UI boad
	& 13(O) & C12(O)	L14(!O) ON	L14 wrong color	Change UI boad
	L14(O) ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B8 (optional)	L11 & L12 & L13 & L14 OFF			
Press button B9		L15 OFF	L15 damaged	Change UI boad
		L15(!O) ON	L15 wrong color	Change UI boad
		Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B9		L16 OFF	L16 damaged	Change UI boad
	L15(O) & L16(O)	L16(!O) ON	L16 wrong color	Change UI boad
	ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B9		L17 OFF	L17 damaged	Change UI boad
	L15(O) & L16(O)	L17(!O) ON	L17 wrong color	Change UI boad
	& L17(O) ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B9 (optional)	L15 & L16 & L17 OFF			
Press button B10		L21 OFF	L21 damaged	Change UI boad
(only 3B&3C)		L21(!O) ON	L21 wrong color	Change UI boad
		Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B10		L22 OFF	L22 damaged	Change UI boad
(only 3B&3C)	L21(O) & L22(O)	L22(!O) ON	L22 wrong color	Change UI boad
	ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad



Press button B10		L23 OFF	L23 damaged	Change UI boad
(only 3B&3C)	L21(O) & L22(O)	L23(!O) ON	L23 wrong color	Change UI boad
	& L23(O) ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B10 (optional)	L21 & L22 & L23			
(only 3B&3C)	OFF			
Press button B11		L18 OFF	L18 damaged	Change UI boad
		L18(!W) ON	L18 wrong color	Change UI boad
	L10(0) ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B11		L19 OFF	L19 damaged	Change UI boad
	L18(O) OFF &	L19(!B) ON	L19 wrong color	Change UI boad
	L19(B) ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B11 (optional)	L18 & L19 OFF			
Press button B12		L20 OFF	L20 damaged	Change UI boad
		L20(!O) ON	L20 wrong color	Change UI boad
	L20(0) ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B12 (optional)	L20 OFF			
Press button B13		L27 OFF	L27 damaged	Change UI boad
		L27(!O) ON	L27 wrong color	Change UI boad
	L27(0) ON	Other Lx toggle	Short circuit in Leds or Buttons	Change UI boad
Press button B13 (optional)	L27 OFF			

Finish condition: NO BU, NO drag drawer,	LED INDICATION
Door open, No Water	All Leds OFF (in case that also optional was done)

### Legenda

Text	Group	Description
Press button Bx	Sequence of actions by user	Press the button Bx. Valid in all
		models
Press button Bx (only X&Y)	Sequence of actions by user	Press the button Bx. Valid only in
		the model X & Y
Press button Bx (optional)	Sequence of actions by user	Press the button Bx. Not
		requested but if the operator will
		do it the machine will react in the
		descripted way.
Lx (y) ON	Reaction of the appliance	The led Lx switches On with the
		color y. Color code:
		y=W -> color White
		y=R -> color Red
		y=O -> color Orange
Lx OFF	Reaction of the appliance	The led Lx switches Off.
Lx (!y) ON	Reaction of the appliance	The led Lx switches On with a
		different color from the expected
		y. FAILURE MODE.

# Test mode

## Level 2 (Loads and sensor)

Start condition: NO BU, NO drag drawer, Door open, No Water

Sequence of actions by user				
	PASS	FAIL	Cause of failure	Solution
Check the start condition		L24(!R) ON	L24 wrong color	Change UI boad
		L25(!R) ON	L25 wrong color	Change UI boad
			L24 damaged	Change UI boad
			Water level sensor damaged (short circuit)	Change Water level sensor
		L24 OFF	Connector JP14 in Main damaged (short circuit)	Change Main boad
	L24(R) & L25(R)		uP U2 in Main damaged (short circuit in Pin9)	Change Main boad
	ON		L25 damaged	Change UI boad
			The Microswitch is not well placed	Check assembly of microswitch
		L25 OFF	Microswitch damaged (short circuit)	Change microswitch
			Connector JP3 in Main damaged (schort circuit)	Change Main boad
			uP U2 in Main damaged (short circuit in Pin26)	Change Main boad
Insert BrewUnit & Close Door (No Dump Box)	No changes	L25 OFF	Assembly issue of the microswitch or mechanical lever.	Check microswitch position and mechanical lever.
Insert a full water tank			The floater in the Water tank is blocked or missing	Check the floater in the Water Tank
			Water level sensor not in position	Change the position of Water level sensor
			Water level sensor damaged (open circuit)	Change Water level sensor
	L24(R) OFF	L24 remain ON	Wiring of the water level sensor not connected	Check the wiring
			Wiring of the water level sensor damaged (open)	Change the wiring
		uP U2 in Main damaged (open circuit in Pin9)	Change Main Boad	
Insert Dreg drawer and drip	L25(R) OFF	L25 remain ON	The Microswitch is	Check assembly of

LED INDICATION	
L24 & L26 ON	



## Test mode

# Test mode

trav			not well placed	microswitch
			Microswitch	
			damaged (open	Change microswitch
			circuit)	change moreewiten
			Wiring of the	
			winny of the	Check the wiring
			microswictimiot	Check the winnig
			wining of the	Observed the societies
			microswicth	Change the wiring
			damaged (open)	
			uP U2 in Main	
			damaged (open	Change Main boad
			circuit in Pin26)	
Brew Unit				
Press and release B2 to			Wiring of the BU	
move BU to work.			motor not	Check the wiring
N.B:			connected	_
* If the BU is already moving			Wiring of the BU	
to home then stop the			motor damaged	Change Main Board
movement and change the			(open)	
direction into work.			Motor of BU	
* If the BU is already moving		BU not move	damaged	Change the BU motor
to work then stop the			The drive of the	
movement	L1(O) ON while BU		motor in the Main is	Change Main Roard
	is moving.		domogod	Change Main Board
				Chask the DU
			BU DIOCKED	
			Gears or motor not	Check the assembly
			well assembled	of the gear and motor
		BU move to	Wiring of BU motor	Check the Motor BU
		Home	are inverted	wiring
		_	The absorbed	Check the assembly
		L26 ON	current exceed the	of the gear and
			limit (200ma).	motor, check the BU
			The BU	Check assembly of
			Microswitch is not	BLL microswitch
			well placed	
			BU Microswitch	Change BLI
			damaged (open	microswitch
	L1(O) Dlink when		circuit)	meroswiten
	LI(U) Blink when	Plink and PU	Wiring of the BU	
	builds reached	OFF Work not	microswicth not	Check the wiring
			connected	
	011	reacheu	Wiring of the BU	
			microswicth	Change the wiring
			damaged (open)	
			uP U2 in Main	
			damaged (open	Change Main boad
			circuit in Pin26)	5
Press and release B3 to			Wiring of the BU	
move BU to home			motor not	Check the wiring
N.B:			connected	
* If the BU is already moving	L3(O) ON while BU	BU not move	Wiring of the RU	
to work then stop the	is moving.	BU HUL HIUVE	motor damaged	Change the motor BU
movement and change the			(onen)	wiring
direction into home				Change the PLL motor
				Change the BU motor

* If the BU is already moving			damaged	
to home then stop the			The drive of the	
movement.			motor in the Main is	Change Main Board
			damaged	
			BU blocked	Check the BU
			Gears or motor not	Check the assembly
			well assembled	of the gear and motor
		BU move to	Wiring of BU motor	Check the Motor BU
		Work	are inverted	wiring
			The absorbed	Check the assembly
		1.26 ON	current exceed the	of the dear and
			limit	motor check the BLI
			The BLI	
			Microswitch is not	Check assembly of
			well placed	BU microswitch
				Change BU
			damaged (open	microswitch
	L3(O) Blink when	L3 OFF & L26		
	BU has reached	Blink and BU	Wiring of the BU	
	home position, BU	OFF. Home not	microswicth not	Check the wiring
	OFF	reached	connected	
			Wiring of the BU	
			microswicth	Change the wiring
			damaged (open)	
			uP U2 in Main	
			damaged (open	Change Main boad
			circuit in Pin26)	
EV1				
EV1 Press and release B5 to	[		Wiring of the EV1	Check the wiring
EV1 Press and release B5 to toggle the EV. If it was			Wiring of the EV1 not connected	Check the wiring
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open.		The "click" is no	Wiring of the EV1 not connected Wiring of the EV1	Check the wiring
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open.	L7(O) OFF -> ON.	The "click" is no audible. The EV	Wiring of the EV1 not connected Wiring of the EV1 damaged (open)	Check the wiring Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open.	L7(O) OFF -> ON. It's possible to bear the "click"	The "click" is no audible. The EV remain closed	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged	Check the wiring Change Main Board Change the EV1
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open.	L7(O) OFF -> ON. It's possible to hear the "click".	The "click" is no audible. The EV remain closed	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the	Check the wiring Change Main Board Change the EV1
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open.	L7(O) OFF -> ON. It's possible to hear the "click".	The "click" is no audible. The EV remain closed	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is	Check the wiring Change Main Board Change the EV1 Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open.	L7(O) OFF -> ON. It's possible to hear the "click".	The "click" is no audible. The EV remain closed	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged	Check the wiring Change Main Board Change the EV1 Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open. Press and release B5 to	L7(O) OFF -> ON. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open. Press and release B5 to toggle the EV. If it was	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF.	The "click" is no audible. The EV remain closed The "click" is no audible. The EV	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open. Press and release B5 to toggle the EV. If it was open, then will be closed.	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open. Press and release B5 to toggle the EV. If it was open, then will be closed.	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open. Press and release B5 to toggle the EV. If it was open, then will be closed. EV2	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open.  Press and release B5 to toggle the EV. If it was open, then will be closed.  EV2 Press and release B12 to	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open.  Press and release B5 to toggle the EV. If it was open, then will be closed.  EV2 Press and release B12 to toggle the EV. If it was	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged Wiring of the EV2 not connected	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open.  Press and release B5 to toggle the EV. If it was open, then will be closed.  EV2 Press and release B12 to toggle the EV. If it was closed, then will be open	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged Wiring of the EV2 not connected Wiring of the EV2	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open.  Press and release B5 to toggle the EV. If it was open, then will be closed.  EV2 Press and release B12 to toggle the EV. If it was closed, then will be open.	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged Wiring of the EV2 not connected Wiring of the EV2 damaged (open)	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board Change Main Board Check the wiring Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open. Press and release B5 to toggle the EV. If it was open, then will be closed. EV2 Press and release B12 to toggle the EV. If it was closed, then will be open. ONLY FOR LATTEGO	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click". L20(O) OFF -> ON. It's possible to	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged Wiring of the EV2 not connected Wiring of the EV2 damaged (open) EV2 damaged	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board Check the wiring Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open. Press and release B5 to toggle the EV. If it was open, then will be closed. EV2 Press and release B12 to toggle the EV. If it was closed, then will be open. ONLY FOR LATTEGO	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click". L20(O) OFF -> ON. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open The "click" is no audible. The EV remain closed	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged Wiring of the EV2 not connected Wiring of the EV2 damaged (open) EV2 damaged	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board Check the wiring Change Main Board Change the EV2
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open. Press and release B5 to toggle the EV. If it was open, then will be closed. EV2 Press and release B12 to toggle the EV. If it was closed, then will be open. ONLY FOR LATTEGO	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click". L20(O) OFF -> ON. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open The "click" is no audible. The EV remain closed	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged Wiring of the EV2 not connected Wiring of the EV2 damaged (open) EV2 damaged The drive of the EV2 in the Main is	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board Check the wiring Change Main Board Change the EV2
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open. Press and release B5 to toggle the EV. If it was open, then will be closed. EV2 Press and release B12 to toggle the EV. If it was closed, then will be open. ONLY FOR LATTEGO	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click". L20(O) OFF -> ON. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open The "click" is no audible. The EV remain closed	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged Wiring of the EV2 not connected Wiring of the EV2 damaged (open) EV2 damaged The drive of the EV2 in the Main is damaged	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board Check the wiring Change Main Board Change the EV2 Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open.  Press and release B5 to toggle the EV. If it was open, then will be closed.  EV2 Press and release B12 to toggle the EV. If it was closed, then will be open. ONLY FOR LATTEGO	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click". L20(O) OFF -> ON. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open The "click" is no audible. The EV remain closed	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged Wiring of the EV2 not connected Wiring of the EV2 damaged (open) EV2 damaged The drive of the EV2 in the Main is damaged	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board Change Main Board Change Main Board Change the EV2 Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open.  Press and release B5 to toggle the EV. If it was open, then will be closed.  EV2 Press and release B12 to toggle the EV. If it was closed, then will be open. ONLY FOR LATTEGO  Press and release B12 to toggle the EV. If it was	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click". L20(O) OFF -> ON. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open The "click" is no audible. The EV remain closed	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged Wiring of the EV2 not connected Wiring of the EV2 damaged (open) EV2 damaged The drive of the EV2 in the Main is damaged EV2 damaged	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board Change Main Board Change Main Board Change the EV2 Change Main Board
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open. Press and release B5 to toggle the EV. If it was open, then will be closed. EV2 Press and release B12 to toggle the EV. If it was closed, then will be open. ONLY FOR LATTEGO Press and release B12 to toggle the EV. If it was on LY FOR LATTEGO	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click". L20(O) OFF -> ON. It's possible to hear the "click". L20(O) ON -> OFF. It's possible	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open The "click" is no audible. The EV remain closed	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged Wiring of the EV2 not connected Wiring of the EV2 damaged (open) EV2 damaged The drive of the EV2 in the Main is damaged EV2 damaged	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board Change Main Board Change the EV2 Change Main Board Change the EV2
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open. Press and release B5 to toggle the EV. If it was open, then will be closed. EV2 Press and release B12 to toggle the EV. If it was closed, then will be open. ONLY FOR LATTEGO Press and release B12 to toggle the EV. If it was open, then will be closed.	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click". L20(O) OFF -> ON. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged Wiring of the EV2 not connected Wiring of the EV2 damaged (open) EV2 damaged The drive of the EV2 in the Main is damaged EV2 damaged	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board Change Main Board Change the EV2 Change Main Board Change the EV2
EV1 Press and release B5 to toggle the EV. If it was closed, then will be open. Press and release B5 to toggle the EV. If it was open, then will be closed. EV2 Press and release B12 to toggle the EV. If it was closed, then will be open. ONLY FOR LATTEGO Press and release B12 to toggle the EV. If it was open, then will be closed. Press and release B12 to toggle the EV. If it was open, then will be closed.	L7(O) OFF -> ON. It's possible to hear the "click". L7(O) ON -> OFF. It's possible to hear the "click". L20(O) OFF -> ON. It's possible to hear the "click". L20(O) ON -> OFF. It's possible to hear the "click".	The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open The "click" is no audible. The EV remain closed The "click" is no audible. The EV remain open	Wiring of the EV1 not connected Wiring of the EV1 damaged (open) EV1 damaged The drive of the EV1 in the Main is damaged EV1 damaged The drive of the motor in the Main is damaged Wiring of the EV2 not connected Wiring of the EV2 damaged (open) EV2 damaged The drive of the EV2 in the Main is damaged EV2 damaged	Check the wiring Change Main Board Change the EV1 Change Main Board Change the EV1 Change Main Board Change Main Board Change the EV2 Change Main Board Change the EV2



Press and release B4 to switch on the Pump (100 impulses). With the EV open the water gase out from the			Wiring of the Flowmeter not connected	Check the wiring
HotWater spout. With the EV closed the water goes out from the Coffee spout.	L5(O) ON & L19(B) BI INK followig the	L5 ON & L19 remain OFF, Pump ON and after 5sec.	Viring of the Flowmeter damaged (open)	Change the wiring
			Flowmeter	Change the
			damaged	Flowmeter Change Main Deard
		ON, Pump OFF.	Main damaged (short circuit)	Change Main Board
	impulses of the flowmeter	·	uP U2 in Main damaged (short circuit in Pin18)	Change Main Board
		L5 ON & L19	Wiring of the PUMP not connected	Check the wiring
		remain OFF, Pump OFF, and	Wiring of the PUMP damaged (open)	Change Main Board
		after 5sec. L5	PUMP damaged	Change the PUMP
		Pump OFF.	The drive of the Pump in the Main is damaged	Change Main Board
ThermoBlock and NTC				
Press and release B8 to toggle the ThermoBlock.			Wiring of the NTC not connected	Check the wiring
Check the absorbed current. In this case we suppose that		L26 ON	Wiring of the NTC damaged (open)	Change the wiring
was OFF, then will be ON			NTC damaged	Change the wiring
100%.			Main damaged (short circuit)	Change Main Board
		uP U2 in Main damaged (short circuit in Pin24)	Change Main Board	
			TB damaged	Change the TB
	L11(0) OFF->ON	The current is out of range	The drive of the TB in the Main is damaged	Change Main Board
		L11(O) OFF & L26(R) Blink	The TB has reached the max temperature.	Brew water to reduce the temperature. And repeat the test.
			Wiring of the TB not connected	Check the wiring
			TCO open	Change the TCOs
		The current is very low <0.5A.	Wiring of the TB damaged (open)	Change the wiring
		,,	TB damaged	Change the TB
			in the Main is damaged	Change Main Board
Press and release B8 to toggle the ThermoBlock. Check the absorbed current < 0,5A. In this case we suppose that was ON, then	L11(0) ON->OFF	The current is still present>0,5A.	The drive of the TB in the Main is damaged	Change Main Board

# Test mode

will be OFF.				
Grinder				
Press and release B9 to toggle the Grinder. If it was OFF, then will be ON and			Wiring of the Grinder not connected	Check the wiring
will move in clockwise direction.		L15 OFF & L26	Wiring of the Grinder damaged (open)	Change the wiring
		<b>UN</b>	Grinder damaged	Change the Grinder
	L15(O) OFF->ON		Grinder blocked	Change the Grinder
			The drive of the Grinder in the Main is damaged	Change Main Board
		The rotation direction is wrong: anti- clockwise	Wirings of Grinder are inverted	Check the Grinder wiring
Press and release B9 to toggle the Grinder. If it was ON, then will be OFF.	L15(O) ON->OFF	The grinder is still rotating.	The drive of the Grinder in the Main is damaged	Change Main Board

N.B:

If the Dreg drawer is not inserted or the Service door is not closed the following loads cannot be tested: 1. BU 2. EV



# **Functions/features explanation**

### Steam out

The machine enters in Steam-Out mode by pressing in sequence B4, B2, B5, B3 (drawing like an "S") in the first two seconds after inserting the plug into the socket. (Please make sure to avoid any serial connection on Main board white connector).



Once entered the machine checks the following conditions:

- The Ntc sensor must work correctly; if there is a failure on NTC (Ntc disconnected or in short circuit) the operation cannot be performed and the L26 will blink (turn off the machine and repair before do Steam-out operation).
- The DREGDRAWER must be in place and the DOOR must be closed; if someone is not in place the operation cannot be performed and the L25 will blink. To start again the operation insert drag drawer and close service door.
- If these 2 conditions are respected the machine will start automatically the Steam Out process showing L18 and L20 flashing in series.

If, during the Steam Out, the Door is opened or drag drawer is removed L25 will be switched on. To start again the operation insert drag drawer and close service door.

At the end of the procedure L25 and L26 turns on.

When the Steam-Out is complete the following parameters are reset to their default values:

Default valuesDescriptionsSee specificationsLength "Espresso" productSee specificationsLength "Coffee" productSee specificationsLength "HotWater" productSee specificationsLength "HotWater" productSee specificationsLength "Americano" product, coffeeSee specificationsLength "Americano" product, waterSee specificationsLength "Cappuccino" product, coffeeSee specificationsLength "Cappuccino" product, coffeeSee specificationsLength "Latte Macchiato" product, coffee

Parameters	Default values
Temperature setting	Medium
Coffee Grounds	Reset counter
Aroma (all drinks)	Medium
Pre selected quantity (coffee, water and milk)	Medium
Error log [i]	0
Ellor log [i]	0
BU Unloaded Current Array[1]	150
Gr_time_aroma [Light]	3000
Gr_time_aroma [Medium]	3500
Gr_time_aroma [Strong]	4000
Filter_autonomy	0
Filter_counter	0
Filter_startup_qty	See requirement

## **Coffee specifications**

Drinks	Low button	Medium button	High button	Volume adjustment
	( ml)	(ml)	(ml)	(only at high button - ml)
Espresso	30	40	70	40-220
Coffee	100	120	200	120-220
Espresso lungo	60	80	180	80-220
Americano	40	40	40	40
(water)	(50)	(110)	(160)	(110-360)
Cappuccino	30	40	60	40-220
(milk)	(90)	(120)	(200)	(120-340)
Latte macchiato	30	40	50	40-220
(milk)	(120)	(200)	(340)	(200-340)
Hot water	60	150	360	150-360

### **Philips EP Series**

- Descriptions
- Temperature setting Number of grounds in dregs drawer Aroma for all drinks Restore the default length (medium)

Array Error saved in machine resetted Array of last 4 brew unit effort during rinsing cycle (in milliamperes).  $\rightarrow$  Autozero for new autodose system

- Grinding time for aroma 1 (ms) Grinding time for aroma 2 (ms) Grinding time for aroma 3 (ms) Autonomy of last Aqua clean filter actived Number of Aqua clean filter actived in aqua-clean chain
- nt Counter of water for enable first Aqua Clean filter; if expire, the machine need a descaling action to activate a new filter.



## Descaling

Please use Philips descaler only. Under no circumstances should you use a descaler based on sulfuric acid, hydrochloric acid, sulfamic or acetic acid (vinegar) as this may damage the water circuit in your machine and not dissolve the limescale properly. Not using the Philips descaler will void your warranty. Failure to descale the appliance will also void your warranty.

### When the Calc / Clean light starts to flash slowly, you need to descale the machine.

- 1. If attached remove LatteGo or milk frother.
- 2. Remove the drip tray and the coffee grounds container, empty them and put them back into place.
- 3. Remove the water tank and empty it. Then remove the AquaClean water filter.
- 4. Pour the whole bottle of Philips descaler in the water tank and then fill it with water up to the Calc/ Clean indication. Then place it back into the machine.
- 5. Place a large container (1.5 l) under the coffee dispensing spout and the water spout.
- 6. Press the Calc / Clean icon for 3 sec. and then press the start/stop button.
- 7. The first phase of the descaling procedure starts. The descaling procedure lasts approx. 30 minutes and consists of a descaling cycle and a rinsing cycle. During the descaling cycle the Calc / Clean light flashes to show that the descaling phase is in progress.
- 8. Let the machine dispense the descaling solution until the display reminds you that the water tank is empty.
- 9. Empty the water tank, rinse it and then refill it with fresh water up to the Calc / Clean indication.
- 10. Empty the container and place it back under the coffee dispensing spout and the water spout. Press the start/stop button again.
- 11. The second phase of the descaling cycle, the rinsing phase, starts and lasts 3 minutes. During this phase the lights on the control panel go on and off to show that the rinsing phase is in progress.
- 12. Wait until the machine stops dispensing water. The descaling procedure is finished when the machine stops dispensing water.
- 13. The machine will now heat up again. When the lights in the drink icons light up continuously, the machine is ready for use again.
- 14. Install and activate a new AquaClean water filter in the water tank
- 15. When the descaling procedure is finished, the AquaClean light flashes for a while to remind you to install a new AquaClean water filter.

### What to do if the descaling procedure is interrupted

You can exit the descaling procedure by pressing the on/off button on the control panel. If the descaling procedure is interrupted before it is completely finished, do the following:

- 1. Empty and rinse the water tank thoroughly.
- 2. Fill the water tank with fresh water up to the Calc / Clean level indication and switch the machine back on. The machine will heat up and perform an automatic rinsing cycle.
- 3. Before brewing any drinks, perform a manual rinsing cycle. To perform a manual rinsing cycle, first dispense half a water tank of hot water by repeatedly tapping the hot water icon and then brew 2 cups of pre-ground coffee without adding ground coffee.

If the descaling procedure was not completed, the machine will require another descaling procedure as soon as possible.

# **Functions/features explanation**

### **Temporany solutions** Cable tie for the pump

To make sure the pump won't move from its place. The pump will be assembled with a cable tie. In case a swap is needed, please follow these step to place it back:

them inside:



- 2. In pictures 1 and 2 you can see the exactly position where to place the cable tie.
- 3. Don't close it too much: the leftover cable needs to be 5cm to guarantee the proper tightness (picture 3)



### **Philips EP Series**

1. Start inserting a cable tie (20cm x 1,2mm) in the empty space of the pump holder, then keeping both pull



## **Temporany solutions**

### Tape for service door

- Before the shipment of the appliances, is required to apply 4 pcs of adhesive tape as shown in picture.
- 1. Do not cover the water sensor area (in red)
- 2. Do not leave any gap between the tape and the corner (green arrows)



# Functions/features explanation

## **Espresso Philips Service Center (EPSC)**

EPSC is the Service tool to upload the software on the machine and run the diagnostic mode. It can be downloaded from the following link: https://www.epsc.philips.com/ServiceCenterPortal/ The application can be used only in combination with the Saeco Programming Device: Cod. 996530009845 "KIT PROGRAMMER SERKIT SSC2" A new cable 421946047151 "WIRING SERPROG OMN PROGRAMMER ASSY." is required. They can be ordered as spare parts.

All details related to the registration and operation are explained in the enclosed Quick start guide (QSG).

### Espresso Philips Service Center– Quick Start Guide

Press the icon to view the document

To open the attached document is necessary to save the service manual on your PC. The main Diagnostic Parameters description is available on the GDA\_114331.



In order to connect the machine to the PC, we need to remove the back panel, which will expose the complete mainboard

### **REMEMBER:** The board is working at 230V

Please take extra care before you start to open the machine or connect/disconnect the programmer cable, as till the USB programmer, high voltage is going through



### **Philips EP Series**

For your safety, be sure the plug is



# **Functions/features explanation**

## Deactivate AquaClean filter reminder

If you would like to deactivate or turn off the AquaClean filter reminder on your Philips 1200/2200/3200 espresso machine, follow the steps below.

- 1. Switch OFF the machine
- 2. Press and hold the AquaClean button for 3 seconds until the AquaClean icon light is on and the start/ stop button starts blinking
- 3. Press the start/stop button again to turn off the AquaClean icon light
- 4. Your AquaClean filter reminder is now deactivated

Note: Once deactivated, you will not receive any notification after you descale your machine. If you wish to use AquaClean filter in the future, can activate it again by pressing the AQ filter icon for 3 seconds

## Deactivate the beeping sound of the buttons

It is possible to deactivate the beeping sound, please follow the instructions below:

- 1. Press the ON/OFF button to switch OFF the machine
- 2. Press and hold the Coffee icon (or Espresso Lungo icon for Philips EP3221 model) for 3 seconds
- 3. The x1 cup light of the Coffee icon is light up and START/STOP light starts to blink. This indicates that the sound setting is set to ON.
- 4. Press the Coffee icon again to switch the x1 cup light icon off. The sound setting is now set to off.
- 5. Press the start/stop button to save the setting
- 6. Press the ON/OFF button to switch the machine back ON.

Note: Deactivating the beeping sound is not possible for the on/off button and the start/stop button

### Reset drinks settings to default setting

- 1. Switch OFF the machine
- 2. Press and hold the Espresso icon for 3 seconds
- 3. The screen will show the default settings on the aroma strength/pre-ground coffee icon, drink quantity icon, milk quantity icon (specific models only), coffee temperature icon (specific models only)
- 4. Start/stop button will start to pulse, indicating that the settings are ready to be restored
- 5. Press the start/stop button to confirm you want to restore to the default settings
- 6. Press the ON/OFF button to switch the ON again

### **Repair Flow**

Proces stap	Saeco no.		Action
Intake		1	Visual inspection (transport dam
		2	Check Type/serialnumber
		3	Log all available accessory, coun
Diagnosis		4	Check product for consumer co
		5	Run Diagnostic to get error code
		6	Opening machine
Repair		7	Repairing the fault(s) encounter
		8	Checking any modifications (view
			Refer Annex tabs per family (if
		9	Basic Functional test while the
			detected)
Coffee			Make e 2 cups at the same time
- Crema			Blow on the coffee. Does the cre
			Is the crema colour correct (Haz
- Temperature			Is the coffee temperature within
Steam			Does the steam work
Hot Water			Does the hot water work
Milk			(if applicable)
- Cappuccino			Does the cappuccinatore produc
		10	check water circuit for any leaka
		11	Check machanism for good may
		12	Assembly
Increation		12	Assembly
nspection		13	Do cabinet parts fit well togethe
- VISUAI		14	Check for damages
- Power check		15	Will the set switch on
- Accessories		10	Do the accessories match with t
- Consumer complaint		1/	Check the product for the consu
Quick Functional test		18	Make 2 cups at the same time. A
Coffee		19	Is the sound normal ?
Leakage		20	Did the product leak during the
Steam Out			Steam out before chinning out
			Ne need for these families Min
			Intolia V2 · Philing 2000 2100 ·
		21	heek for CDA 112455
		21	cneck for GDA_113455
Reset Error code			New devices like Xelsis-New hav
		22	to see if it appear afterwards ag
Claim Administration			Provide precise IRIS code, acco
			from the part you have worked
			view !
		23	Primary fault and correspondin
Cleaning		25	Clean water reservoir, bean rese
		26	Clean and dry brew unit, coffee
		27	External cleaning (housing surfa
Safety check		28	Earth leakage, Isolation test, res
			or H-POT TEST
Visual		29	Check the mains cord for damage
Packing		30	Packing
		31	Check completeness (accessorie
		32	Neatly pack the product
Documentation		33	Info for Consumer by packed ? e
		34	Descaling instruction with chang
Repair report		35	Is there an answer to ALL consu
		36	add set statistic and give, if need
		37	Is it indicated which documents
		38	Are there tips how to prevent is

nage) take care for pictures

ter check with info from consumer mplaint and main function (NFF contact consumer) s and relevant set statistics (EPSC) refer SDA\_114585

ed (view Symptom Cure) w Symptom Cure, new software, etc.) available) appliance is open (linked to consumer complaint or what you may have

Are the volumes equal ema come back together elnut)

spec refer SDA\_97832

e good froth

age, such as Oetiker clamps, boiler and valve connection and hoses

ement and unexpected noise

he intake

imer complaint

Are the volumes equal

testing

if temperature is below 0° to prevent any damaged due to frozen water. uto Family (all platform); Incanto Family New .; Pico Baristo ; Gran Baristo; Incanto Executive; Xelsis-New; Moltio Family (all Platform) Please also

ve the possibility to reset the error code, once captured it need to be reset

rding dedicated code table for Garment Care products. The location code I on MUST be completed always with the part reference from exploded

g IRIS code should be claimed first.

ervoir, brew chamber and conveyor

bin and drip trav

ce)

istor of earth wire grounding, as requested in certain country's (VDE, ISO)

ges

es) according income log refer #3

.g. service brochure, FAQ, NFF letter, s/c etc...

ged procedure (S/C) if available

mer questions/complaints (see complaint)

ded clear instruction towards consumer are added

sues



28/03/19 Version 1.0 : Initial release.



